

Disable Code 128

1



Disable Interleaved  
2 of 5 (ITF)



2

Disable Code 93

3



Enable STX Prefix



4

When enabled, the scanner will transmit a Start of Text (ASCII 02H) before each bar code.

Do not Transmit  
UPC-A Check Digit

5



Expand UPC-E to  
12 Digits



6

Expand UPC-E bar codes to the 12 digit equivalent, UPC-A bar codes.

Do Not Transmit  
EAN-13 Check Digit

7



Scanner will not transmit EAN-13 Check Digit.